



Look up, down and all around in the backyard

Before you play, stop and scan the area

Look UP for:

- Power lines above fences, trees and roofs.
- Tree branches or toys close to power lines.
- Things stuck on power lines, like kites or balloons.

If something is stuck near a power line, tell an adult. Don't touch it!

Look DOWN for:

- Cords, tools or plugs outside.
- Wet grass or puddles near electrical items.
- Broken lights or extension cords.

Electricity and water don't mix!

Look ALL AROUND for:

- Dangers where you might run or throw something.
- Pets, siblings and friends nearby.
- Safe spaces to play away from electricity.

Choose a clear, open space to play safely.



Look up, down and all around at the school playground

Before you play, stop and scan the area

Look UP for:

- Power lines near play equipment.
- Poles or electrical boxes nearby.
- Objects flying too high, like balls, frisbees or kites.

Never throw things toward power lines.

Look DOWN for:

- Wet ground after rain.
- Metal objects near electrical boxes.
- Cracks or tripping hazards.

Walk – never run – near anything electrical.

Look ALL AROUND for:

- Friends using equipment near you.
- Clear paths to run and play.
- Adult supervisors if something looks unsafe.

If something looks wrong, **stop and tell an adult.**



Look up, down and all around on a neighborhood street

Before you play, stop and scan the area

Look UP for:

- Power lines along the street.
- Tree branches touching power lines.
- Poles near sidewalks or yards.

Stay far away from fallen or low-hanging lines.

Look DOWN for:

- Cords across yards or sidewalks.
- Puddles near electrical equipment.
- Broken lights or open boxes.

Never touch something electrical on the ground.

Look ALL AROUND for:

- Cars, bikes and buses.
- Dangers where you might walk or ride.
- A safe adult if you need help.

If you see a downed power line: **Stop. Stay back. Get help.**